


SMART MX (V5) Plus interactive display

Need some help with your display?
Check out these basic troubleshooting tips.



Turn on the display

Press the Power button  on the front control panel.



Connect your computer

Connect a computer to your display using an HDMI cable and, to enable touch, a USB cable.

You can also use a single USB-C cable to connect a computer for both video and touch.

Interact with the computer's desktop

After connecting a computer, press the Input Select button  on the Home screen, then tap the computer's input menu option.

Need to share your screen? Visit smarttech.com/smartmirror.

Sign in

Sign in to a Google or Microsoft account to personalize your display, download lesson files for quick access, and more. If your account is connected to a Lumio or SMART Notebook Plus account, you can sync lesson files directly to the display.

To sign in, tap  on the navigation bar at the bottom of the screen.



Write and erase

Pick up one of the display's pens and write or draw in digital ink. To erase, move your fist or palm over the ink.

Use the iQ features

The display's iQ features are available without connecting a computer. Tap the Home button  to access them.

Read about the iQ features in the SMART Board display teacher guide (support.smarttech.com/docs/software/iq/4/en/teacher-guide/default.cshml#).

